www.cype.com



AcoubatBIM by CYPE





AcoubatBIM by CYPE

AcoubatBIM by CYPE is a tool developed by CYPE and the CSTB (Centre Scientifique et Technique du Bâtiment) with the aim to help users study the insulation and acoustic conditioning of buildings. It calculates the indices that evaluate the insulation of airborne sound (indoor and outdoor), impact sound insulation and the reverberation level in indoor spaces, in accordance with the procedure contained in the EN ISO 12354:2017 code.



CUDE | Software for Architecture, Engineering and Construction

Area of application

AcoubatBIM by CYPE is able to carry out the design and calculation of the insulation and acoustic conditioning of any type of building, complying with different predefined regulations included in the application, using customized configurations of other regulations, or utilising personal technical understanding:

Country	Standard
	Nouvelle Réglementation Acoustique (NRA)
۲	Regulamento dos Requisitos Acústicos dos Edificios (RRAE)
	Determinazione dei requisiti acustici passivi degli edifici (D.P.C.M. del 5 diciembre 1997)
♦	NBR 15575
347	Configurable standards

Principal characteristics

User interface

The AcoubatBIM user interface is divided into two tabs:

· Model.

The main parameters of the project are specified in this tab, as well as the acoustic properties of each component of the building that intervenes in the analysis. To do so, the program contains a library where the acoustic properties of all the elements can be defined to then apply them to each component of the building.



Calculation.

Once the model has been defined, users can launch the analysis in this tab. The program allows users to inspect the results obtained for each space and each element that is involved, so they can be compared to the levels required by the code.



Acoubat database

AcoubatBIM incorporates the sound trial database of the Acoubat analysis engine, which is managed by the CSTB. Each product is classed in accordance with the following categories depending on its use in the building:

- Traditional masonry
- · Load bearing walls and concrete slabs
- Partitions
- · Lightweight partitions
- Floor covers
- Linings
- Doors and windows
- Technical equipment
- · Suspended ceiling and access floors
- · Curtain wall facades
- · Thermal bridge breaker
- Absorbing object
- Roofing



The program includes a search engine based on product reference and a comparison tool that allows the acoustic behaviour curves of up to four products to be superimposed in order to facilitate the final choice.

Apart from the products that Acoubat incorporates by default, the program allows adding new elements through the manual introduction of its acoustic characterization, with the possibility of using them in any project.

In addition, thanks to the copy and paste options, it is possible to insert the acoustic values of each test in the customized product quickly and precisely. This can be done by copying the data directly from a spreadsheet or through the connection with the acoustic system behaviour prediction program, **AcouSYS**, developed by the CSTB (Centre Scientifique et Technique du Bâtiment).





The products of the database are assigned by users to the types of elements defined in the program library (in the "Model" tab).

General parameters

Calculation options.

The user can indicate to the program what global acoustic index he wants to evaluate each type of isolation.



• Types of spaces for the acoustic calculation.

The program offers the possibility of defining a library of types of enclosures, and assigning to each of them isolation limit values to outdoor airborne noise and noise coming from adjacent buildings. Together you can activate the calculation of reverberation time and acoustic absorption inside.

• Types of equipment noise.

In order to evaluate the noise generated by the building's equipment, the application allows the establishment of different types of noise and verifies the sound pressure level of the machines belonging to each one of them.

· Interaction between different types of spaces.

AcoubatBIM allows users to calculate the level of indoor airborne noise insulation and impact sound between pairs of spaces based on their type. Users can indicate limit levels for each acoustic magnitude in order to verify the code in force.

Definition of spaces

The particular enclosures of the building must be linked to one of the existing typologies, in addition to introducing their geometric characteristics such as volume and surface. This data can be obtained from the information contained in the BIM model, in case it is being operated within the Open BIM workflow.



Use units

The spaces of the building can be grouped in use units. The values for indoor airborne noise insulation and impact sound insulation that have been indicated in the Interaction between space types section, will not be calculated for pairs of spaces of the same use unit, unless indicated otherwise in "Space definition".

The spaces that do not belong to a use unit can be grouped in "Spaces without an assigned use unit", this way the program understands they act as independent units.

Walls

Users can define types of vertical separators such as facades, partitions and basement walls in the program library. The construction solution of the base element can be selected and internal and/or external linings can be introduced.



Once the types have been defined, they can be assigned to the spaces of the project, where their location and dimensions can be assigned. Similarly, the program allows users to indicate whether there are doors, windows or openings in partitions or facades.

For the calculation of insulation against outdoor airborne sound, for vertical facades of the building, AcoubatBIM by CYPE allows users to include the level difference due to the shape of the facade for the shape facades and orientations of the sound source, as indicated in the **EN ISO 12354-3:2017** code.

Floor slabs

Horizontal separation elements are defined in a similar manner as are walls except, in these cases, the selected products can contain impact sound data. Contained in this group are screeds, floor slabs and roofs.

As occurs with walls, users can select a bottom cladding (dropped ceiling) and top cladding (floor covering).



Openings

The definition of the types of openings like doors, windows, and skylights is completed from the program's library. The openings are introduced in each enclosure of the work, where its area is specified and related to one of the classes defined in the library.

In the case of windows, the user can assign a blind box type of the database, which will be calculated as an independent opening.



Aerators

Unlike the rest of the gaps, the aerators are characterized by the normalized sound level difference of the element, $\mathbf{D}_{n'e'}$ instead of by the noise reduction index, R. Once the typologies in the program library have been defined, they can be inserted in the walls in the same way that it is carried out with the doors, windows and skylights.



Equipment

The application allows the introduction of sound sources in the building. For each of the sources of the library, an operating class must be specified, according to the types of noise introduced previously in the general parameters of the project. Likewise, to indicate the acoustic properties of the machine, the equipment must be related to one of the products of the Acoubat database.

The equipment can be introduced in a specific room or

to access the enclosure where the source is located and add a new element in the list that makes reference to the corresponding typology of the library. The external equipment, on the contrary, is introduced in a specific section within the application tree. In addition, indicate the distance between the source and the closest enclosure of each affected area (r) and, depending on the surfaces near the source, the value of the directivity factor (Q) of the machine.

Connections

AcoubatBIM allows users to define the connections between construction elements of the project, which are required to determine the vibration reduction index, K_a, which is used in the indirect or flanking sound transmission. Users can indicate which components make up the connection, the angles formed between them and the length of the connecting edge, I_u.

	American	IN 14 CANE - + 70	Blokel - KA. Allieses				– n x
	tor e						
Consult Region Acade They have been been been been been been been be	Ra Cerr Lan						Under Mate
General data Una unte	- but						Bill model
et have	Correctors						
a to Low	BZO	**					
0 C Unrada	Felerance	U	in m			Langh	Owded
8-10 201 powersor	251,525,42	in N	Billiok and 1345Concerts-1	of 1930-Clinics pat	Chrw	2.16fm	
203-foor 2	294,535,40	2 11	FFor del Clincle parties	(Original and the second		157m	
(g-11) 284 (log)	294,578,0	10 TT	U Billinek and 13 Billinek and	1300 Cardent patter	(38)	2.400 m	
@-19 St1 -Office 2	29(333,0	04 Th	V Blittek wal 10-Blittek wal	780/18/80		2.700 m	8
8-07 52 000 B	29(,505,10	15 CI	A Climble settion-Different	and 1990-Black wa	1350-TPlor etal	00 1315 e	-
g-10 504-08ue 5	29(,535,0	26 N	Block and 15-Block and 1	3/02		1.415 m	×
AS' E .	Longh Librery	3315 H 28 Of EDinates	attion (Sillanonte and 1980)	Ellino val 1350-P/N	- 10.0		
0		Type .	Argin	Denert			
		2 🖬 Kal	0	20CSUW08	8		
		2 E Foreita	10	201,021,001	8		
		3 🔜 tot	180	28,528,009	8		
		4. E Foreido	270	255_538_FC1	1		

Furniture

Three-dimensional objects, such as people or furniture, with absorption area values can also be introduced inside spaces. These devices increase the sound absorption area of the space and consequently, reduce the reverberation time.



Absorbent layers

The absorbent layer library allows the introduction of 2D absorption elements in the model of the work. These, like furniture, are not taken into account in the calculation of acoustic insulation and only influence the prediction of the level of reverberation inside the space where they are installed.

As the types of absorbent layers are characterized by their sound absorption coefficient (α), they must be associated with the interior or exterior face of an enclosure.

Open **BIM**

Integration in the Open BIM workflow

AcoubatBIM by CYPE is an application intergrated in the Open BIM workflow. This integration is carried out through the exchange of IFC information files with a previously defined BIM model.



Link to a BIM project.

The reading of a BIM model is done from files in IFC format generated by CAD / BIM programs such as IFC Builder, Allplan, Archicad or Revit. This allows "AcoubatBIM by CYPE" to automatically incorporate the enclosures and the constructive elements that make up the building.

If the IFC file that is imported has been generated by IFC Builder, during the import process, the unions between separators and the edges that make them up are also processed, so that the user does not need to define unions manually.

In addition to the geometry, AcoubatBIM allows other IFC entities to be integrated in the calculation model, such as:

• Baths and showers.

These objects, together with the rest of the sanitary equipment, can be introduced through IFC Builder.

- Terminal elements of air conditioning ducts.
 For example, grids and diffusers can be entered in the BIM program for the design of air conditioning systems CYPETHERM HVAC.
- VRF systems, Multisplit and Split 1x1.
 In the same way as the grids and diffusers, it is possible to introduce them in CYPETHERM HVAC.
- Exporting information in the IFC files.

AcoubatBIM by CYPE exports IFC files with the documentation of the acoustic study, in PDF format ("Listing of results", "Characteristics of the materials" and "Table of materials").

• Synchronisation with the BIM model.

Whenever there is a modification in the BIM model, the program can incorporate the changes into the AcoubatBIM project enabling the user to work in parallel with the specialists of other disciplines.

Results and checks

Once the analysis has been carried out, AcoubatBIM allows users to view the magnitude of the evaluated sound values, so they can analyse the results in the most efficient manner depending on their needs.



Global indices

When the analysis process has ended, a general summary, in histogram format, is displayed which allows users to quickly identify the values of the global sound indices that lie outside the allowable range.





AcoubatBIM by CYPE displays a drop-down menu, for each receptor space, with the results of the global indices that have been selected to measure each sound magnitude. If the verification of a limit value has been selected, it will be viewed next to the value obtained for the sound index.

When work is carried out on a BIM model, a result is selected from the list, the elements involved in the analysis (pairs of spaces, connections, partitions...) are highlighted in the 3D view of the building.

Detailed results

For each analysis that is carried out, the program offers users the option to generate a report containing the values obtained in octave third bands. The document also includes information regarding the analysis, such as the spaces involved and formula used.

The results for each frequency can be viewed in three different ways:

Results.

A table and graph of the results are displayed in third octave bands of the sound index.

· Analysis (Table).

The results, in third octave bands of the sound index, are displayed in table format, as well as the values of the variables used to calculate them.

• Analysis (Graph).

The results, in third octave bands of the sound index, are drawn on a graph, as well as the values of the variables used to calculate them.

Finally, each of the paths of the connections (directflanking, flanking-direct and flanking-flanking) can be inspected, as well as the values obtained for the velocity difference in the connection (D_{vii}) .

Documentation

When the calculation by AcoubatBIM by CYPE has been completed the following project listings are automatically generated:

Results list.

AcoubatBIM by CYPE compiles a document as a summary with the results of the global acoustic indices obtained for each enclosure together with the verification of the limit values established by the user. It is also possible to configure the elements that you wish to display, being able to see only the enclosures that do not meet the requirements or the values obtained for each separator and each joint.

		Page	president						
	- I	< < 3	P H [1 of 19				🔒 Pent.	- R
Z01 -	ground floor								
Dining	100m								
Turne	Desta cast								
Volume	171.9 m ²								
Reverber	allos	Area				Velue	Required	Vel	/w)
Tr (arfu	mished) 2	07.34 mil				1.50 .	Tr 50.90 +	+ 0.60	
Servicee	seion fermaliog	0	sa (65)	C((6) C	5+{#5}_L	-AT (454)	Required (15A)	Veri	14
CHEN	DV#					27	5 27	*	
Dave	1907								
	Dente à Gava_Bea_BQVJ)								
						21			
08.0	3								
5	ounce 8 (202 805 8003)		56	12	.7	-32			
office	4								
5	ownee 6 (202_505_5001)		.59	-2	-8	-55			
Hall									
2	dommon Area								
and a	Common Area								
golume	197.43 m*								
Reverber	etion	Area				Value	Required	Veri	é e
man Currillan	ni(had)	248.32 (**)				18-00 44	1 21.16 44		
The states	nagametarroonesona	area; Laviora	i ceit,ei	(m) C (c)	1 CV (d)	ti cn7,4(d	to secured (di	U Veri	
3 201 6	now	17.24 m ³	53		- 2	52	2.45	•/ •	
3 0	CHART & (2011 \$600 W/01)	8.95 mil	91	-14	-25	99			
8 0	ening 1 (201_502_W01_01)	3.65 m8		-1		63			
8 0	lening 2 (201_602_W01_62)	1.21 m2	89		-4	64			
2 0	ening 3 (201_502_901_63)	1.21 m4	29	-3	-8	50			
10 Os	ening 4 (205_502_W01_04)) 1.21 m ^a	59	+5	-4	50			
5 4	teral 1	\$.067 m	67	-1	-6	66			
2 1	feral 2	3.403 m	105	-14	-23	94			
- S - M	66/81 3	3.403 m	200	-14	-27	94			
8	10/01 4	4.060 m	82		-10	74			
G. Contract	hulding	17.86.00	54				2.40		
201.6	82 W/01	27.56 ml				57	5 m/		
0	(#15 L (201, 802, W0L)	27.04.003				40			
	derel 1	8.020 m	67			65			
	nerel 2	3,403.01	82			78			

· Characteristics of the materials.

The program extracts the set of files corresponding to the acoustic tests of the materials used in the project contained in the Acoubat database.

 					C) HILL	- UL - HT DEPO	4.
	Sou	ind reducti	on index		_		
Product	Concrete	17 cm					
Class	Solid cond	rete					
Origin	Traditiona	Icroducts					
Mass	400 ka/m	2					
Thickness	0.17 m						
90		THEFT	Freq	R	1		
			50	43.3	1		
			63	42.8			
80			80	42.3			
		/	100	41.8			
		1 1 1	125	39.7			
£70		1	160	44.6			
		1	200	47.5			
8			250	49.4			
200		×	315	52.3			
-	1		400	55.2			
3	1		500	57.1			
See.	1		630	59.0			
Eov	1		800	61.0			
2 1	1		1000	62.9	1		
2.11		1 1 1 1	1250	65.9	1		
840			1600	6.65			
8			2000	70.8			
			2500	158	1		
30			3150	74.8	1		
			4000	118			
			5000	81.6	-		
20			1 12	08	_		
63 125	280 500	1000 2000 400					

· Table of materials.

The application generates a list that relates the types of elements defined in the project and the products of the Acoubat database that have been assigned to them. Additionally you can see the total area occupied by the enclosures in the work and the number of each type of door, window, skylight and aerator.

	Page penden	
	H 4 2 9 H 2#5	E Pert.
-		
100	Materials list	
-	English	Date: 01/19/3
1F/	AÇADES	
1.1	Brick wall 13 (457.9 m²)	
	Base element	
Produc	E COGETHERM Pumise stone blocks 200 mm in thickness with 15 mm per side	ment mortar on one
Class	Masonry In Hotow concrete block	
Origin	COGEBLOC	
M555	215 Kg/m*	
Thickne	ess 0.22 m	
	Internal cover	
Produc	Interior cladding ISOCOMBO 140; cRw,heavy =14dB	
Class	Wall lining with celular foam	
Ortigin	UNILIN-BVBA	
Hose	14 kg/m ²	
Chickne	ess 0.17 m	
Å2	Brick wall 17 (159.12 m³)	
5	Base element	
Chald	E concrete 17 cm	
Trania.	Traditional conducts	
Contra Co	Adda log (m)	
Buches	1 1 2 m	
2	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	
£3	Defence (29.44 m ²)	
2	Base element	
Poduc	5 Concrece 20 cm	
Class	Solid concrete	



AcoubatBIM by CYPE

AcoubatBIM by CYPE is an application intergrated in the Open BIM workflow. This integration is carried out through the exchange of IFC information files with a previously defined BIM model.



Technical Documents

Avda. Eusebio Sempere, 5 03003 ALICANTE - SPAIN Tel. (+34) 965 922 550

United States of America: CYPE Engineering Software 1201 Peachtree St., 400 Colony Square Atlanta, GA, 30361 Tel: (+1) 202 569 89 02 Tel: (+1) 404 870 90 46

United Kingdom: Tel. (+44) 20 3608 1448

cype@cype.com http://store.cype.com www.cype.com



Software for Architecture, Engineering and Construction